

03 ORGANE PONT AR

385 PONT AR P 385



CHASSIS MZ 221/222
PONT AR P 385


03	385	00	N° DE PLANCHE
----	-----	----	------------------

Carter de pont AR	01
Nez de pont AR	02
Plateaux de freins AR	03
Moyeux AR	04

ÉDITION 15-1-65

03	385	00	01/04
1	2	3	4

- 1 ORGANE DE BASE
- 2 TYPE D'ORGANE
- 3 N° CATALOGUE
- 4 N° PLANCHE



03	385	00	01
ORGANE DE BASE	TYPE D'ORGANE	N° DE CATALOGUE	N° DE PLANCHE

CARTER DE PONT AR

03	385	00	01
1	2	3	4

5	6	7	8	5	6	7	8	5	6	7	8
001	292901	CARTER PONT									
002	292903	TROMPETTE									
003	116310	FUSEE									
004	436503	BOUCHON									
005	39925	JOINT									
006	278948	PORTE JOINT									
007	110708	JOINT									
008	218728	ARBRE DE ROUE									
009	208892	JOINT									
010	218607	GOUJON									
011	400942	RONDELLE									
012	208639	ECROU									
013	218722	JOINT 224300									
014	298113	NEZ DE PONT									
015	210581	VIS									
016	405684	RONDELLE									


1	ORGANE BASE					5	REPÈRE				
2	TYPE ORGANE					6	N° PIÈCE				
3	N° CATALOGUE					7	DÉSIGNATION				
4	N° PLANCHE					8	OBSERVATIONS				

03	385	00	02
1	2	3	4

NEZ DE PONT AR

5	6	7	8	5	6	7	8	5	6	7	8
001	218680	SUPPORT		034	251383	VIS					
002	251376	VIS		035	251384	FREIN					
003	251377	FREIN		036	298056	COUPLE 16 57					
004	220525	VIS		037	204041	ROULEMENT					
005	405684	RONDELLE		038	218688	RONDELLE					
006	218695	COUVERCLE		039	218689	ECROU					
007	218690	CALE 0 10		040	298856	BOITIER GAUCHE					
008	218691	CALE 0 15		041	298856	BOITIER DROIT					
009	251378	VIS		042	218678	VIS					
010	405683	RONDELLE		043	218679	ECROU					
011	292904	COUPLE 13 29		044	218714	ANNEAU EXT					
012	204042	ROULEMENT		045	218715	ANNEAU INT					
013	218697	ENTRETOI 12 30		046	204046	ROULEMENT					
014	218698	ENTRETOI 12 35		047	292899	ECROU					
015	218699	ENTRETOI 12 40		048	218718	RONDELLE					
016	218700	ENTRETOI 12 45		049	218719	ECROU					
017	218701	CALE 0 20		050	218720	ECROU REGLAGE					
018	218702	CALE 0 50		051	204045	ROULEMENT					
019	204043	ROULEMENT		052	251382	ANNEAU					
020	218708	CALE 0 10		053	218673	RONDELLE					
021	218709	CALE 0 15		054	251373	ERGOT					
022	218696	CARTER PIGNON		055	218672	PLANETAIRE					
023	251380	GOUJON		056	218675	CROISILLON					
024	405683	RONDELLE		057	218676	SATELLITE					
025	251381	ECROU		058	218677	BUTEE					
026	251378	VIS		059	218721	FREIN ECROU					
027	218703	JOINT ETANCHE		060	251384	FREIN					
028	292898	BRIDE		061	251383	VIS					
029	218707	FREIN									
030	218706	ECROU									
031	204044	ROULEMENT									
032	251379	ANNEAU D ARRET									
033	251374	BOUCHON									

1	ORGANE BASE					5	REPÈRE				
2	TYPE ORGANE					6	N° PIÈCE				
3	N° CATALOGUE					7	DÉSIGNATION				
4	N° PLANCHE					8	OBSERVATIONS				



03	385	00	02
ORGANE DE BASE	TYPE D'ORGANE	N° DE CATALOGUE	N° DE PLANCHE

PLATEAUX DE FREINS AR

03	385	00	03
1	2	3	4

5	6	7	8	5	6	7	8	5	6	7	8
001	216954	SUPPORT	47								
002	129167	BAGUE INT									
003	129168	BAGUE EXT									
004	271746	SUPPORT BAGUE	66820								
005	211050	TOLE PROTECT									
006	400121	VIS									
007	400932	RONDELLE									
008	116617	VIS									
009	133676	FREIN									
010	218725	CAME DROITE									
011	218726	CAME GAUCHE									
012	116620	RONDELLE									
013	400772	GOUPILLE									
014	272308	JEU DEMI MACH									
015	130604	GARNITURE									
016	116665	GALET									
017	116762	AXE									
018	95572	GOUPILLE CANN									
019	400759	GOUPILLE									
020	272308	JEU DEMI MACH									
021	130604	GARNITURE									
022	116619	AXE MACHOIRES									
023	214349	BAGUE MACHOIRE									
024	95572	GOUPILLE CANN									
025	400759	GOUPILLE									
026	116664	ANNEAU									
027	62346	AXE									
028	125770	RESSORT									
029	211049	DEFLECTEUR									
030	400121	VIS									
031	400932	RONDELLE									
032	410502	GRAISSEUR									


1	ORGANE BASE					5	REPÈRE				
2	TYPE ORGANE					6	N° PIÈCE				
3	N° CATALOGUE					7	DÉSIGNATION				
4	N° PLANCHE					8	OBSERVATIONS				

03	385	00	04
1	2	3	4

MOYEUX AR

5	6	7	8	5	6	7	8	5	6	7	8
001	211042	MOYEU NU									
002	99046	ROULEMENT EXT									
003	99047	ROULEMENT INT									
004	211041	TAMBOUR									
005	272349	PORTE JOINT									
006	209951	JOINT									
007	211043	GOUJON DE ROUE									
008	114952	FREIN D ECROU									
009	82327	ECROU									
010	115070	ECROU									
011	218607	GOUJON									
012	400942	RONDELLE									
013	208639	ECROU									
014	114125	RONDELLE									
015	125750	ECROU DE FUSEE									
016	114128	RONDELLE									
017	41388	FREIN DE VIS									
018	404587	VIS									
019	511277	PORTE JANTE AS	36								
020	275729	PORTE JANTE AS	37								
021	113830	GOUJON									
022	113831	ECROU									
023	115073	CERC MICHELIN									
024	210865	CERCLE DUNLOP									
025	211054	ENTRET MICH	38								
026	219903	ENTRET DUNLOP	39								
027	210863	ENTRET DUNLOP	40								
028	115074	ENTRET MICH	41								
029	95589	RALLONGE									

1	ORGANE BASE				5	REPÈRE				
2	TYPE ORGANE				6	N° PIÈCE				
3	N° CATALOGUE				7	DÉSIGNATION				
4	N° PLANCHE				8	OBSERVATIONS				



03	385	00	04
ORGANE DE BASE	TYPE D'ORGANE	N° DE CATALOGUE	N° DE PLANCHE